

Quick Storage Estimate

Micro Drainage

Variables

FSR Rainfall

Return Period (years)

Region

Map

Ratio R

Cv (Summer)

Cv (Winter)

Impermeable Area (ha)

Maximum Allowable Discharge (l/s)

Infiltration Coefficient (m/hr)

Safety Factor

Climate Change (%)

Analyse OK Cancel Help

Enter Climate Change between -100 and 600

Quick Storage Estimate

Micro Drainage

Results

Global Variables require approximate storage of between 5512 m³ and 7439 m³.

These values are estimates only and should not be used for design purposes.

Analyse OK Cancel Help

Enter Climate Change between -100 and 600