



 : UNIT DEMISE
 : BUILDING DEMISE
 : TENANT PARKING

E: INCOMING ELECTRIC SUPPLY
W: INCOMING WATER SUPPLY
BT: INCOMING BT CONNECTION
EV: EVCP DUCT
SP: SPARE DUCT
FW: FOUL WATER DRAINAGE POINT

