

STOP AND THINK

DOES THAT BELONG DOWN THE SINK?

If fats, oils, greases and leftover food go down the drains, they can result in blockages, causing problems for your store, your customers and the local community.

To control this risk, you should follow these simple procedures at all times in your store.



Always scrape any food waste, melted cheese and cornmeal from pans, utensils and equipment into the bin before washing up.



Always scrape any food waste from makeline bins and catch trays into the bin before washing up.



Always wipe sauce bottles containing oily liquids with a paper towel prior to washing. Dispose of the paper towel in the bin.



Always use strainers in the sink plug holes and empty any trapped food waste into the bin.



Never sweep food waste into floor drains, always place rubbish and debris into the bin.